

RD Series: LED Recessed Downlights

Installation Guide for 701977-4(X)DTW1, 701977-4ACCW1

New Construction:

1. Locate desired location and cut round hole in mounting surface with diameter:
 RDS (Small) 110 mm
 RDL (Large) 165 mm
 RDA (Adjustable) 140 mm
 Additional features may be required.
2. Go to Installation section below.

Retrofit:


1. Lockout primary power.
2. Remove existing luminaire and driver.
3. Go to Installation section below.

NOTE: Compatible with ceiling tile thicknesses up to 25 mm.


Power Supply Compatibility Table

| Primary Watts | RDS (Small) | RDL (Large) | RDA (Adj.) |
|--------------------|--------------|--------------|--------------|
| | 15 W | 21 W | 21 W |
| Philips Driver P/N | 9290 014 101 | 9290 014 102 | 9290 014 102 |


Installation:




1. Remove plastic cover of driver housing primary terminals.




2. Push primary wiring into N and L terminals on primary side push-in connector.




3. Replace plastic cover.



4. Lay driver on top of mounting surface, and connect luminaire to driver with polarized connector.



5. Push spring clips to vertical and slide luminaire into circular opening in ceiling.



6. Verify luminaire operates properly. If adjustable, rotate luminaire body to desired position.



RD Series: LED Recessed Downlights

Installation Guide for 701977-4(X)DTW1, 701977-4ACCW1

Installation Template:

NOTE: Installation template **MUST BE PRINTED AT 100% SCALE.** For instructions, reference documentation for your particular printing software/hardware.

